

## How to install CMDFlash on win7 64 bit

please read carefully the following instructions:

CMD Flashtec SA will be not liable for any damage, loss of profit or any issue due to the following procedures.

warning: 64bit FTDI drivers are not 100% tested and seem to be plenty of bugs

remember that you need a **32bit windows XP pc where cmdflash sw is properly installed and working**

- 1) Unplug cmdflash interface from the 32 bit XP and 64 bit pc
- 2) download FTDI driver [http://www.cmdtec.it/downloads/CMD20814\\_Setup.exe](http://www.cmdtec.it/downloads/CMD20814_Setup.exe)
- 3) execute it on the 32 bit XP and 64 bit pc
- 4) contact [support@flashtec.ch](mailto:support@flashtec.ch) and ask to enable 64bit version on your profile
- 5) plug cmdflash interface on the 32bit XP machine and **update** it to version 3.2.0.98 or greater ( also if you have already downloaded it ) , this will enable the 64bit activation on the interface.
- 6) start the sw on the 32bit pc and follow instructions, an update message will be prompted then wait until it will show "DONE" and then "ready..." in green.
- 7) unplug cmdflash interface from 32bit XP pc
- 8) run CMDFlash setup on the 64bit pc and plug CMDFlash interface only when requested